

Manuale d'uso - Efficienza Energetica / User Manual - Energy Efficiency / Manuel de l'utilisateur - L'efficacité énergétique / Handbuch - Energieeffizienz / Handboek - Energie-efficiëntie Manual - Eficiencia Energética / Manual - Eficiência Energética / Manuell - Energieeffektivitet / Manuell - Energieeffektivitet / Manuaalinen - Energy Efficiency / Manual - Energieeffektivitet Руководство - Энергоэффективность / Käsiraamat - Energiatõhususe / Rokasgrāmata - Energieeffektivitātes

Table with 12 columns: PF (Brand/Model), IT (Description), EN (Description), FR (Description), DE (Description), NL (Description), ES (Description), PT (Description), SV (Description), NO (Description), FI (Description), DK (Description), RU (Description), ET (Description), LV (Description). Rows include product details for FABER P2112, energy efficiency classes (AEchood, EEC, FDEhood, FDEC, LEhood, LEC, GFEhood, GFEC, Qmin, Qmax, Qboost, SPEmin, SPEmax, SPEboost, P0, Ps, PI), and technical specifications (F, Qbep, Pbp, Qmax, Wbep, WL, Emiddle, Lwa) with detailed instructions for use.

